


Abweichend von den Angaben in der Bedienungsanleitung ist die Kamera in Verbindung mit dem **Schraubdeckel ohne Mikrofonloch** jetzt wasserdicht **bis max. 30 Meter (4 bar Prüfdruck)**, wenn die Dichtungen sauber sind und korrekt eingelegt sind. Schraube bitte nur handfest anziehen. Im Wasser wird auch ohne Schall-Loch ausreichend Schall zum Mikrofon übertragen!



Mit dem **Schraubdeckel mit Mikrofon-Schallschlitz** ist die Camera nur **spritzwasserfest**. Dieser Deckel kann bei allen Outdoor- Anwendungen, z.B. beim Fahrrad- oder Motorrad-Fahren, Jogging, Skilaufen usw. benutzt werden, aber **keineswegs im Wasser beim Schwimmen oder Tauchen**.





Different from the user manual the camera is now **waterproof up to 30 meters** (test pressure 4 bar), if the **closed sealing cap without microphone hole** is used and the **sealing rings will be clean and correctly inserted**. Under water sound is sufficiently recorded even without microphone hole.



If you use the **sealing cap with the**

microphone sound slot, then the camera is **only spray water resistant** against normal rain or snow and can be used during outdoor activities, like biking, jogging, skiing, but **never under water for swimming or diving**.

