
AM+FM Versions: Close AM and AM 1 jumpers Delete Scan and Scan 1 jumpers

> No change at CH 9 /19 jumpers

AE 4100 / 4180 Front panel jumpers for AM/FM switch



channel switch

A/F switch programming jumpers

Volume/Squelch

Display